







### Receiving a Message




1. When you receive a new message, your phone displays the  (message waiting) indicator and a **New Message** notification, and gives an alert. If reminders are turned on, your phone sends a reminder every five minutes until you close the new message notification, read the message, or turn off your phone.



2. Use the right soft key  to open the message or the message center if there are multiple messages. Within the message center scroll down using the  to highlight the inbox. Press the right soft key  to select.



3. Use the  to highlight the text message that you want to read and press the right soft key  to read.

4. Read the message and press the left soft key  to save the message, the right soft key  to delete the message or the Menu key  to obtain additional options including:

**Call Back** – Call the number embedded in the message

**Reply** – respond directly to the message received

**Forward** – forward the message to someone else

**Lock** – lock or unlock the message

**Store** – store the sender's number into your phone book

**Delete** – delete this message only

**Delete All** – delete all messages in the in box that aren't locked




**Create Message** – create a new text message


**Setup** – setup your text message inbox





**Note** - Based on standard menu layout. You or your service provider may have modified the menu structure.



### Selecting a Text Entry Mode



1. To activate a text mode, press  from any text entry screen and select the text mode from the Entry Method menu.
2. Use the  to highlight the text mode that you want to use and press the right soft key  to select.



Mode	Access
<b>ITAP™</b> (English, French, Spanish, Portuguese) Let the phone predict each word as you enter it, then choose the word from a list.	<ol style="list-style-type: none"> <li>1. Press each letter key once. For example, to enter "any," press:   →  → </li> <li>2. Use the * or # to cycle through the words at the bottom of the display.</li> <li>3. When you see the word you want, press the right soft key .</li> </ol>
<b>Tap Method</b> Enter characters one at a time by pressing the key for the letter, number, or symbol. This is the standard mode for entering text on your phone.	<ol style="list-style-type: none"> <li>1. Press a number key one or more times to select a letter or number.</li> <li>2. Continue pressing number keys to enter the remaining characters.</li> <li>3. Press OK to store the text when you are finished.</li> </ol>
<b>Numeric</b> Enter only the number that appears on each key.	<ol style="list-style-type: none"> <li>1. Press a key once to enter the number on the key.</li> <li>2. To switch easily between Numeric and Tap methods simply press and hold a number key.</li> </ol>
<b>Symbol</b> Enter symbols only.	<ol style="list-style-type: none"> <li>1. Press a number key one at a time.</li> <li>2. Press * or # or the number key multiple times to highlight the symbol you want.</li> <li>3. Press Select to add the highlighted symbol to the text area at the top of the display.</li> </ol>
<b>Browse</b> Browse through your phonebook and recent calls lists to select a name or number to enter OR browse through your Quick Notes options.	If you are in the "To:" field of entry, selecting the BROWSE entry method will allow you to browse through your phone book or received calls or dialed calls to select an entry.  If you are in the "Msg:" field of entry, selecting the browse entry method will allow you to browse through your list of Quick Notes and select an entry.

### Sending a Message



1. Select Message Center either by pressing the right soft key  or by pushing the menu key  and scrolling to the Create Message option.
2. You can create and send a text message to one or more recipients. The text message feature lets you manually enter each recipient's phone number or email address, or you can choose to browse and select one or more numbers/addresses from the phonebook or recent calls lists. After you have addressed the text message enter OK using the right soft key.


by Motorola




### Sending a Message (continued)




4. Enter your message using letters and/or numbers and select OK.



5. Before sending you have the option to adjust the priority level to urgent, enter a call back number and elect to receive a delivery receipt.



6. After you have made all of your selections select done using the left soft key .

7. You will be provided with a choice to send the message now. If you choose not to send the message you will be prompted to save the message or exit without saving.


### Sending a Preformatted Text Message

Quick notes are short, pre-written text messages that you can create, select, edit, and send quickly (for example, Meet me at ...). You can also create new quick note messages and store them for later use. To send a Quick note:




1. Select Message Center either by pressing the right soft key or by pushing the menu button and scrolling to the Messages option.




2. Within the Message Center Menu select the Create Message option using the right soft key .






3. After you have addressed the text message enter OK using the right soft key.





4. Highlight the message field and select CHANGE using the right soft key .


5. Once the Message section is open select Browse using the right soft key  to browse through the quick note options.

6. Scroll through the quick note options using the up and down arrow keys  and  and use the right soft key  to select the option you want. The text will appear in the message line where you can add additional text or select OK to proceed to sending the message.

### Launching the Internet Browser



1. Press menu  and scroll down to highlight Browser. Use right soft key to select.

2. To exit the browser press end  at any time.

Mobile Web by VZW with MSN is a consumer wireless Internet access offering that gives customers access to rich communication applications, content from over 30 different providers and access to personalized information.

Key Features Include:

- MSN Messenger**
- MSN Hotmail**
- MSN Calendar**
- Alerts**

Mobile Messenger: Two-way messaging CDMA phone required to send and receive from handset.

Mobile Web: Airtime charges apply to usage and will deplete minutes allowance. Phone will end data call and session after a minimum of 30 seconds of inactivity.

Airtime charges may apply while navigating through this tutorial on your wireless phone.