

SAMSUNG Gear S2

QUICK REFERENCE MANUAL

Device Functions



Setting Up Your Gear S2

Step 1. Charging the Gear S2

- Carefully place the Gear S2 on the charging dock and connect to the charger.



Caution! Use the Samsung charger that came with your device. Use of other chargers may damage the device and void the warranty.

Step 2. Turning Your Gear S2 On and Off

- To turn on the Gear, briefly press and hold the **Power/Home** button.
- To turn OFF, press and hold the **Power/Home** button and tap **Power off**.

Step 3. Pairing your Gear S2 to a smartphone

To connect your Gear and mobile device, install the Samsung Gear app on the mobile device. Launch **Galaxy Apps** or visit apps.samsung.com/gear to download it.

For non-Samsung devices, download the Samsung Gear app from the Google Play™ store.

Compatible with Android 4.4 and later with 1.5GB RAM. Some features may not be available. For best compatibility, connect with Samsung Galaxy devices.

- Gear S2:** Make sure your Gear S2 is turned on.
- Smartphone:** Download the Samsung Gear app from the **Galaxy Essentials** widget.
- Smartphone:** Turn on Bluetooth.

- Smartphone:** Select the Gear S2 model name.

- Smartphone:** When the **Bluetooth pairing request** window displays, tap **OK**.

- Gear S2:** When the connection window displays, tap **OK**.

- Smartphone:** Tap **Finish**.

Activating the Gear S2

Once you have connected the Gear S2 to a smartphone, follow the step below to activate the Gear S2 for standalone use.

- Tap **Activate** and follow the instructions to activate your Gear S2.
- Tap **Restart** when activation is complete.

Home Screen

- Press the **Power/Home** button at anytime to return to the home screen.

Moments Bar

From the clock screen, swipe the screen down to view the notification panel. Quickly forward calls, adjust volume, display brightness and the Do not disturb feature.

Opening the Apps screen

From the home screen, press the **Power/Lock** button.

Notifications

Rotate the Gear S2 bezel to the left to view messages and notifications, or to the right to access Settings and Apps.



